

Triton Turbo XT
Alt = CTRL (FCTN CTRL)

4A/XT Mode - FCTN CTRL ENTER
Right Shift - OPT2.

Reboot XT - FCTN CTRL =
Reset Alpha Lock - FCTN CTRL SPACE

Del	Ins	End	PgUp	Home	PgDn	Tab	Scrl	Esc	PtScr	g+	OPT1 <i>Fctn Shift</i>
F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	=	OPT2 <i>Fctn Enter</i>
Del	Ins	End	PgUp	Home	PgDn	Tab	Scrl	Esc	Bksp	=	FCTN