



Cassette Software

Model PHT 6008

Electrical Engineering Library

Four powerful programs which assist you in designing components for electrical systems.

■ **FILTER DESIGN**—Computes component values for three active filters and two passive filters.

■ **PHASE LOCK LOOP DESIGN**—Calculates design parameters for a basic phase lock loop.

■ **ROOT LOCUS CALCULATIONS**—Computes asymptote intersection point, asymptote angles, and arrival and departure angles from zeroes and poles.

■ **SMITH CHART CALCULATIONS**—Performs various transmission line calculations equivalent to the graphical constructions on the Smith Chart.

Requires the use of cassette tape recorder (not included) for loading the program contents into the TI 99/4 Home Computer memory.

Overview	2
Filter Design	
Description	3
Background	4
User Instructions	9
Example	12
Phase-Locked Loop Design	
Description	13
Background	14
User Instructions	17
Example	19
Root-Locus Calculations	
Description	20
Background	21
User Instructions	22
Example	24
Smith Chart Calculations	
Description	25
Background	26
User Instructions	28
Example	30
Loading Cassettes	32
In Case of Difficulty	34
Limited Warranty	35

Copyright © 1980, Texas Instruments Incorporated.
Program and database contents copyright © 1980, Texas
Instruments Incorporated.

Author: Texas Instruments
Language: TI-99/4 BASIC
Hardware: TI-99/4 Home Computer
Disk Controller and Drive or cassette recorder
Media: Diskette and Cassette

The Electrical Engineering Library is a collection of programs which can assist you in designing components for electrical systems. Each program performs time-saving electrical engineering calculations and thus helps to simplify your design task.


- FILTER DESIGN - Computes component values for the design of active filters (lowpass, highpass, and bandpass) and passive filters (Butterworth and Tchebycheff).
- PHASE-LOCKED LOOP DESIGN - Calculates design parameters for a basic phase-locked loop with either an active or passive loop filter.
- ROOT-LOCUS CALCULATIONS - Computes asymptote intersection point and asymptote angles, and appropriate arrival and departure angles from zeros and poles.
- SMITH CHART CALCULATIONS - Performs various transmission-line calculations equivalent to the graphical constructions on the Smith Chart.

The Filter Design program computes the necessary component values that yield the required performance parameters for various filters. Component values can be computed for both active filters (lowpass, highpass, and bandpass) and passive lowpass filters (Butterworth and Tchebycheff). You specify the performance parameters, such as peak, gain, cutoff frequency, and quality. The computer displays the required capacitances, inductances, and resistances.

The following equations are used to describe each filter system and compute the component values of the filters.

Active Lowpass Filter

The following equations are used to describe the active lowpass filter.



The voltage transfer function for the active lowpass filter shown above is:

$$\frac{E_o}{E_i}(s) = \frac{-1/R_1 R_3 C_1 C_2}{s^2 + \left(\frac{1}{R_1} + \frac{1}{R_3} + \frac{1}{R_2}\right) \left(\frac{1}{C_1}\right) s + \frac{1}{R_2 R_3 C_1 C_2}}$$

The corresponding lowpass network function is:

$$H(s) = \frac{-H_0 \omega_0^2}{s^2 + \alpha \omega_0 s + \omega_0^2}$$

where $H_0 = 10^A/20$ $F =$ cutoff frequency in hertz
 $A =$ passband gain in dB $\alpha =$ peaking factor $= 2\zeta$
 $\omega_0 = 2\pi F$ $\zeta =$ damping ratio


Given A , F , α , and C_2 in microfarads, the program calculates R_1 , R_2 , R_3 , and C_1 , as follows:

$$C_1 = \frac{4(1 + H_0)C_2}{\alpha^2} \qquad R_2 = \frac{\alpha}{4\pi F C_2}$$

$$R_1 = \frac{R_2}{H_0} \qquad R_3 = \frac{R_2}{H_0 + 1}$$

Active Highpass Filter

The following equations are used to describe the active highpass filter.



The voltage transfer function for the active highpass filter shown above is:

$$\frac{E_o}{E_i}(s) = \frac{-(C/C_1)s^2}{s^2 + \left(\frac{2}{C_1} + \frac{1}{C}\right)\left(\frac{1}{R_1}\right)s + \frac{1}{R_1 R_2 C C_1}}$$

The corresponding highpass network function is:


$$H(s) = \frac{-H_0 s^2}{s^2 + \alpha \omega_0 s + \omega_0^2}$$

Given A, F, α , and C in microfarads, the program calculates R_1 , R_2 , and C_1 as follows:

$$C_1 = \frac{C}{H_0} \qquad R_1 = \frac{2H_0 + 1}{2\pi F\alpha C} \qquad R_2 = \frac{\alpha}{2\pi FC(2 + 1/H_0)}$$

Active Bandpass Filter

The following equations are used to describe the active bandpass filter.



The voltage transfer function for the active bandpass filter shown above is:

$$\frac{E_o}{E_i}(s) = \frac{-(1/R_1 C_1)s}{s^2 + \left(\frac{C_1 + C_2}{R_3 C_1 C_2}\right)s + \frac{R_1 + R_2}{R_1 R_2 R_3 C_1 C_2}}$$

The corresponding bandpass network function is:

$$H(s) = \frac{-H_0 \alpha \omega_0 s}{s^2 + \alpha \omega_0 s + \omega_0^2}$$

where $\alpha = 1/Q$
 $Q = F/B$, quality factor measure of selectivity of filter
 $F =$ Center frequency of passband in hertz
 $B =$ 3-dB bandwidth in hertz

Given B , A , F , C_1 , and C_2 in microfarads, the program calculates R_1 , R_2 , and R_3 as follows:



$$R_1 = \frac{Q}{2\pi F H_0 C_1}$$

$$R_2 = [Q(C_1 + C_2)2\pi F - (1/R_1)]^{-1}$$

$$R_3 = \frac{Q}{2\pi F} \left(\frac{1}{C_1} + \frac{1}{C_2} \right)$$

Butterworth Filter

The form of the Butterworth filter, along with its characteristic response, is shown below.



For Butterworth filters with response of the form shown, the component values are computed as follows:

$$C_i = \frac{1}{\pi f_c R} \sin \left[\frac{(2i - 1)\pi}{2n} \right] \quad i = 1, 3, 5, \dots$$



$$L_i = \frac{R}{\pi f_c} \sin \left[\frac{(2i - 1)\pi}{2n} \right] \quad i = 2, 4, 6, \dots$$

where f_c = cutoff frequency in hertz
 n = filter order
 R = terminal resistance in ohms

Note: This program assumes that the generator resistance R_g is equal to the load resistance R_L ; therefore, $R = R_g = R_L$.

Tchebycheff Filter

The form of the Tchebycheff filter, along with its characteristic response, is shown below.



For Tchebycheff filters with response of the form shown, the component values are computed as follows:

$$\beta = \ln \left[\coth \left(\frac{\epsilon}{40 \log e} \right) \right]$$

$$\gamma = \sinh \left(\frac{\beta}{2n} \right)$$

$$a_i = \sin \left[\frac{(2i-1)\pi}{2n} \right] \quad i = 1, 2, 3, \dots, n$$

$$b_i = \gamma^2 + \sin^2 \left(\frac{i\pi}{n} \right) \quad i = 1, 2, 3, \dots, n$$

$$g_1 = \frac{2a_1}{\gamma}$$

$$g_i = \frac{4a_{i-1} a_i}{b_{i-1} g_{i-1}} \quad i = 2, 3, 4, \dots, n$$

$$C_i = \frac{g_i}{2\pi f_c R} \quad i = 1, 3, 5, \dots$$

$$L_i = \frac{Rg_i}{2\pi f_c} \quad i = 2, 4, 6, \dots$$

Note: For odd-order Tchebycheff filters, the generator resistance R_g is equal to the load resistance; therefore, the termination resistance $R = R_g = R_L$. In the case of even-order Tchebycheff filters, $R_L = R_g / \coth^2(\beta/4)$ which, for small ripple, results in the generator resistance R_g being approximately equal to the load resistance R_L . Thus, the termination resistance $R = R_g \approx R_L$.

- STEP 1: Be sure that the disk drive or cassette recorder is attached to the computer and turned on. (See the owner's manuals or the Users Reference Guide for product details.)
- STEP 2: Press any key to pass the title screen. Then press 1 to select TI BASIC. To load the program from diskette, insert the diskette into Disk Drive 1, type

OLD DSK1.FILTERS

and press ENTER.

To load the program from a cassette tape, insert the tape into the recorder. Next, refer to the "Loading Cassettes" section in this manual for instructions on determining the program's position on the cassette tape. When you have inserted the cassette tape and properly positioned the tape counter, type

OLD CS1

and press ENTER. The computer then displays directions for loading the program. Refer to "Loading Cassettes" if you have difficulty in loading the program from the cassette.

- STEP 3: When the cursor reappears, type RUN, and press ENTER. The FILTER DESIGN title screen appears. Press ENTER to display the list of options.

ACTIVE FILTERS:

1. Lowpass
2. Highpass
3. Bandpass

PASSIVE FILTERS:

4. Butterworth
5. Tchebycheff

OR:

6. EXIT PROGRAM

STEP 4: Select the type of filter you wish to design.

OPTION 1: LOWPASS FILTER

If you choose option 1, the program displays a diagram showing the components for a lowpass filter circuit. Next, enter the peaking factor, the passband voltage gain in decibels, the cutoff frequency in hertz, and the value of C2 in microfarads. The program then calculates and displays the values for C1, R1, R2, and R3. To continue, press ENTER, and the program displays the list of options again. You may then calculate values for another filter or choose option 6 to exit the program.

OPTION 2: HIGHPASS FILTER

If you choose option 2, the program displays a diagram showing the components of a highpass filter circuit. Next, enter the peaking factor, the passband voltage gain in decibels, the cutoff frequency in hertz, and the value of C in microfarads. The program then calculates and displays the values for C1, R1, and R2. To return to the list of options, press ENTER. You may then calculate values for another filter or choose option 6 to exit the program.

OPTION 3: BANDPASS FILTER

If you choose option 3, the program displays a diagram showing the components of a bandpass filter circuit. Next, enter the frequency of the passband in hertz, the values of C1 and C2 in microfarads, the quality factor, and the voltage ratio or midband voltage gain in decibels. The program then calculates and displays the values for R1, R2, and R3. To return to the list of options, press ENTER. You may then calculate values for another filter or choose option 6 to exit the program.

OPTION 4: BUTTERWORTH FILTER

If you choose option 4, the program displays a diagram showing the components of a Butterworth filter circuit. Next, enter the filter order ($n < 10$) which defines the number of reactive components, the terminal resistance in ohms, and the cutoff frequency in hertz. If you enter a value that is outside the normal range for a variable, the screen displays "INVALID INPUT -- PRESS ENTER" or a warning message, followed by "PRESS ENTER." To return to the list of options, press ENTER. Enter 4 and reenter your parameters for the Butterworth filter. The program then calculates and displays the values for C1, C3, C5, . . . , and L2, L4, L6 Press ENTER to return to the list of options. You may then calculate values for another filter or choose option 6 to exit the program.

OPTION 5: TCHEBYCHEFF FILTER

If you choose option 5, the program displays a diagram showing the components of a Tchebycheff filter circuit. Next, enter the filter order ($n < 10$) which defines the number of reactive components, the terminal resistance in ohms, the cutoff frequency in hertz, and the allowable ripple in decibels. If you enter a value that is outside the normal range for a variable, the screen displays "INVALID INPUT -- PRESS ENTER" or a warning message followed by "PRESS ENTER." The list of options is displayed when you press ENTER. Enter 5 and reenter your parameters for the Tchebycheff filter. The program then calculates and displays the values for C1, C3, C5, . . . , and L2, L4, L6 To return to the list of options, press ENTER. You may then calculate values for another filter or choose option 6 to exit the program.

OPTION 6: EXIT PROGRAM

If you select option 6, the message **DONE** is displayed, and the program stops.

To help you understand how the program functions, work the following example.

Find the component values for an active bandpass filter with a center frequency of 150 hertz, a midband voltage gain of 30dB, a quality factor of 9.375, and $C1 = C2 = 0.1 \mu F$.

First, load and run the program as described in Steps 1 and 2 of the "User Instructions." Next, enter 3 to select Bandpass Filter design. You are now ready to input the performance parameters of the desired filter.

PROMPT	ENTER	COMMENTS
CTR FREQ?	150	Center frequency in hertz
C1 μF ?	.1	Capacitance in microfarads
C2 μF ?	.1	Capacitance in microfarads
3-DB BW?	9.375	Quality factor (CTR FREQ/BANDWIDTH)
GAIN μ	30	Midband voltage gain in dB

The following answers are displayed.

R1 = 5.37 K Ω
 R2 = 353.4 Ω
 R3 = 339.53 K Ω




To return to the list of options, press ENTER.

The Phase-Locked Loop Design program computes the design parameters for basic phase-locked loops. You are given the option of designing a type-2, second-order loop with an active filter or a type-1, second-order loop with a passive filter. You provide the following information.

N = integer divisor (active filter only)
Gain = the loop gain, sec^{-1}
C = filter capacitance, μF

At this point you have the option of either entering ω , the natural angular frequency in radians/second, and ζ , the damping factor, to solve for the resistances R_1 and R_2 in ohms, or entering the resistances R_1 and R_2 to calculate ζ and ω . In either case, the loop-noise bandwidth is calculated and displayed.

After you choose an appropriate loop filter (active or passive), this program computes the resulting design parameters for a basic phase-locked loop (PLL) as illustrated below.



The basic PLL transfer function is:

$$\frac{\theta_o}{\theta_i}(S) = \frac{GF(S)}{S + GF(S)}$$

- where θ_o = the output phase
- θ_i = the input phase
- G = the loop gain
- F(s) = the transfer function of the loop filter
- G = $K_p K_v$

- where K_p = the gain of the phase detector in volt/radian
- K_v = the gain of the VCO in radians/second-volt

If the loop filter is active, an N counter can be added to the loop, making the output frequency, f_{out} , an integral multiple of the input or reference frequency, f_{in} . Thus, $f_{out} = N f_{in}$, where $N \geq 1$.

For both active and passive filters, the time constants are $\tau_1 = R_1 C$ and $\tau_2 = R_2 C$.

Active Filter Calculations

For an active filter with a very large amplifier gain,

$$F(S) = \frac{Sr_2 + 1}{Sr_1}$$

The ($\div N$) counter changes the form of the PLL transfer function,

$$\frac{\theta_o}{\theta_i}(S) = \frac{GF(S)/N}{S + GF(S)/N}$$

Using the transfer function representative $F(S)$, the PLL transfer function becomes

$$\frac{\theta_o}{\theta_i}(S) = \frac{G(Sr_2 + 1)/Nr_1}{S^2 + S(Gr_2/Nr_1) + G/Nr_1}$$

By inserting the natural angular frequency ω_n and the damping factor ζ for the time constants τ_1 and τ_2 , the PLL transfer function becomes

$$\frac{\theta_o}{\theta_i}(S) = \frac{2\zeta\omega_n S + \omega_n^2}{S^2 + 2\zeta\omega_n S + \omega_n^2}$$

To calculate ω_n and ζ , given R_1 and R_2 ,

$$\omega_n = \sqrt{\frac{G}{Nr_1}} \quad \text{and} \quad \zeta = \frac{\omega_n \tau_2}{2}$$

To calculate R_1 and R_2 , given ω_n and ζ ,

$$R_1 = \frac{G}{N\omega_n^2 C}$$

$$R_2 = \frac{2\zeta}{\omega_n C}$$

Passive Filter Calculations

For a passive filter,

$$F(S) = \frac{Sr_2 + 1}{S(\tau_1 + \tau_2) + 1}$$

Using the transfer function representative $F(S)$, the basic PLL transfer function becomes

$$\frac{\theta_o}{\theta_i}(S) = \frac{G(Sr_2 + 1)/(\tau_1 + \tau_2)}{S^2 + S(1 + Gr_2)/(\tau_1 + \tau_2) + G/(\tau_1 + \tau_2)}$$

By inserting the natural angular frequency ω_n and the damping factor ζ for the time constants τ_1 and τ_2 , the PLL transfer function becomes

$$\frac{\theta_o}{\theta_i}(S) = \frac{S\omega_n(2\zeta - \omega_n/G) + \omega_n^2}{S^2 + 2\zeta\omega_n S + \omega_n^2}$$

To calculate ω_n and ζ , given R_1 and R_2 ,

$$\omega_n = \sqrt{\frac{G}{\tau_1 + \tau_2}} \quad \text{and} \quad \zeta = \frac{\omega_n}{2} \left(\tau_2 + \frac{1}{G} \right)$$

To calculate R_1 and R_2 , given ω_n and ζ ,

$$R_1 = \frac{G}{\omega_n^2 C} - R_2 \quad \text{and} \quad R_2 = \frac{2\zeta}{\omega_n C} - \frac{1}{GC}$$

For both active and passive loops, the one-sided loop-noise bandwidth BW in hertz is calculated using the formula:

$$BW = \frac{\omega_n}{2} \left(\zeta + \frac{1}{4\zeta} \right)$$

- STEP 1: Be sure that the disk drive or cassette recorder is attached to the computer and turned on. (See the owner's manuals or the Users Reference Guide for product details.)
- STEP 2: Press any key to pass the title screen. Then press 1 to select TI BASIC. To load the program from diskette, insert the diskette into Disk Drive 1, type

```
OLD DSK1.PHASELL
```

and press ENTER.

To load the program from a cassette tape, insert the tape into the recorder. Next, refer to the "Loading Cassettes" section in this manual for instructions on determining the program's position on the cassette tape. When you have inserted the cassette tape and properly positioned the tape counter, type

```
OLD CS1
```

and press ENTER. The computer then displays directions for loading the program. Refer to "Loading Cassettes" if you have difficulty in loading the program from the cassette.

- STEP 3: When the cursor reappears, type RUN, and press ENTER. The PHASE LOCKED LOOP DESIGN title screen appears. Press ENTER to display the following list of options:

1. ACTIVE FILTER
2. PASSIVE FILTER
3. EXIT PROGRAM

- STEP 4: Next, choose the type of phase-locked loop (PLL) you wish to design. If you select an active loop filter, you are asked to enter the integer divisor (N), where $N \geq 1$. The remaining data entries for active and passive filters are identical. Enter the loop gain ($G = KpKv$) in sec^{-1} . Next, enter the filter capacitance in microfarads. At this point you are asked to enter either R (calculate resistances R_1 and R_2) or F (calculate natural angular frequency ω and damping factor ζ).

To calculate values for R_1 and R_2 , enter R. Next, enter the natural angular frequency ω in radians/second, and the damping factor ζ . If you enter a value that is outside the normal range for a variable, the message "INVALID INPUT -- PRESS ENTER" is displayed. Press ENTER to display the list of options. You may then begin your calculations again. After you enter all the necessary values, the program then calculates and displays the values for the resistances R_1 and R_2 , and the bandwidth, BW, in hertz. Press ENTER to display the list of options. You may then choose another PLL design or enter 3 to exit the program.

On the other hand, to calculate values for ω and ζ , enter F. You are now asked to enter the values for resistances R_1 and R_2 in ohms. The program then calculates and displays the values for the natural angular frequency ω in radians/second, the damping factor ζ , and the bandwidth, BW, in hertz. Press ENTER to display the list of options. You may then choose another PLL design or enter 3 to exit the program.

STEP 5: When you have completed all calculations, select option 3. The message **DONE** is displayed, and the program stops.

To help you understand how the program works, the following example is provided.

A phase-locked loop has an overall loop gain of 20000. If the passive filter component values are $R_1=5k\Omega$, $R_2=500\Omega$, and $C=50\mu F$, what is the natural frequency, damping factor, and noise bandwidth for the loop?

First, load and run the program as described in Steps 1 and 2 of the "User Instructions." Then select option 2 to calculate values for a passive loop filter. Now enter the required data in response to the prompts shown below.

PROMPT	ENTER	COMMENTS
GAIN?	20000	Enter loop gain
C μF ?	50	Enter capacitance in microfarads
FIND R or F:	F	Calculate ω and ζ , given R_1 and R_2
$R_1-\Omega$?	5000	Enter resistance in ohms
$R_2-\Omega$?	500	Enter resistance in ohms

The results are displayed as follows.

ω = 269.68 R/S
 ζ = 3.378
 BW = 465.43 HZ

To return to the list of options, press ENTER.

The Root Locus Program performs the calculations required to describe a linear system using the root-locus method. You specify the open-loop poles and zeros of the system. The program then calculates the asymptote intersection point, asymptote angles, departure angles from poles, and arrival angles at zeros.

Given an equation of the following form

$$F(s) = \frac{\prod_{i=1}^m (s - z_i)}{\prod_{k=1}^n (s - p_k)}$$

where z_i is a zero and p_k is a pole of $F(s)$, the following equations are used to determine the necessary parameters.

The root-locus has $n-m$ asymptotes. They intersect at the point σ_0 where

$$\sigma_0 = \frac{1}{n-m} \left(\sum_{k=1}^n p_k - \sum_{i=1}^m z_i \right)$$

The angles of the asymptotes, ψ_ν , are calculated using the equation:

$$\psi_\nu = \frac{1}{n-m} (180^\circ + (\nu - 1) 360^\circ) \quad \nu = 1, 2, \dots, n-m$$

The departure angle at any complex pole p_j is

$$\phi_j = \sum_{i=1}^m \angle(p_j - z_i) - \sum_{\substack{k=1 \\ k \neq j}}^n \angle(p_j - p_k) + 180^\circ \quad j = 1, 2, \dots, n$$

The arrival angle at any complex zero z_k is

$$\theta_k = -\sum_{\substack{i=1 \\ i \neq k}}^m \angle(z_k - z_i) + \sum_{k=1}^n \angle(z_k - p_k) - 180^\circ \quad k = 1, 2, \dots, m$$

The program calculates σ_0 , ψ_ν , ϕ_j , θ_k for up to 30th order systems ($n \leq 30$, $m \leq 29$).

- STEP 1: Be sure that the disk drive or cassette recorder is attached to the computer and turned on. (See the owner's manuals or the Users Reference Guide for product details.)
- STEP 2: Press any key to pass the title screen. Then press 1 to select TI BASIC. To load the program from diskette, insert the diskette into Disk Drive 1, type

OLD DSK1.ROOTLOCUS

and press ENTER.

To load the program from a cassette tape, insert the tape into the recorder. Next, refer to the "Loading Cassettes" section in this manual for instructions on determining the program's position on the cassette tape. When you have inserted the cassette tape and properly positioned the tape counter, type

OLD CS1

and press ENTER. The computer then displays directions for loading the program. Refer to "Loading Cassettes" if you have difficulty in loading the program from the cassette.

- STEP 3: When the cursor reappears, type RUN, and press ENTER. The ROOT LOCUS title screen appears. Press ENTER to continue.
- STEP 4: Now enter the open-loop poles, separating each pole with a single space. If you do not separate the poles properly, the program asks you to reenter the poles. Complex poles are entered in the form: $A+JB$, where A and B are numeric values. When the plus sign is typed, the program automatically displays a \pm sign to account for the conjugate complex pole. Press ENTER after typing all poles. Then follow the same procedure to enter the open-loop zeros. The number of poles entered must be greater than the number of zeros entered. If not, the program asks you to reenter the poles and zeros.

STEP 5: The program now calculates and displays the number of asymptotes, the asymptote intersection point, the asymptote angles, the departure angles from poles, and the arrival angles at zeros. To repeat the program, press R and the program asks you for new values. When you finish your calculations press E to exit the program. The message ****DONE**** is displayed, and the program stops.

ROOT LOCUS CALCULATIONS

Example

To help you understand how the program works, the following example is provided.

Find the root-locus parameters for the following function.

$$F(s) = \frac{[s - (-.5 + j)][s - (-.5 - j)]}{(s-0)[s - (-2 + 3j)][s - (-2 - 3j)][s - (-4)]}$$

First, load and run the program as described in Steps 1 and 2 of the "User Instructions." Then enter the data in response to the prompts shown below.

PROMPT	ENTER	COMMENT
ENTER N POLES:	0 -2+J3 -4	Enter poles by inspecting denominator.
?		
ENTER M ZEROS:	-.5+J	Enter zeros by inspecting numerator.
?		

The program displays the following results:

THERE ARE 2 ASYMPTOTES
INTERSECTING AT $\sigma = -3.5$
AT THE ANGLES:
90° - 90°

DEPARTURE ANGLES AT POLES:

0	180°
-2+J3	+147°
-4	0°

ARRIVING ANGLES AT ZEROS:

-.5+J	+122°
-------	-------

PRESS (R)EDO, (E)XIT

Press E. The message ****DONE**** is displayed, and the program stops.

The Smith Chart Calculations program allows you to perform various transmission-line calculations equivalent to the graphical constructions on the Smith Chart. The program makes provisions for lines with attenuation and complex characteristic impedance. You enter the following information:

Z0 = Complex characteristic impedance in ohms

ZL or YL = Termination impedance, ohms or termination admittance in mhos

AC = Attenuation constant in decibels/wavelength

DW = Distance from termination in wavelengths

The program then calculates the following:

Input values:

ZI = Impedance in ohms

YI = Admittance in mhos

VSWR = Voltage standing wave ratio

PCR = Power reflection coefficient

Termination Values:

VSWR = Voltage standing wave ratio

PCR = Power reflection coefficient

The following terms are used in many equations and are defined here for convenience.

AC = attenuation constant
 DW = distance from termination
 Z_0 = characteristic impedance
 Z = impedance*
 z = normalized impedance*
 Y = admittance*
 P = reflection factor* (rectangular coordinates)
 $|P| < P$ = reflection factor* (polar coordinates)
 VSWR = voltage standing wave ratio
 PCR = Power Reflection Coefficient

* Note that a subscript "L" indicates values at termination, and a subscript "i" indicates values at input.

Given Z_0 , Z_L or Y_L , AC, and DW, the following equations are used to calculate input and termination terms. A low-loss line is assumed.

Termination Terms

If Y_L is entered

$$Z_L = \frac{1}{Y_L} \quad \text{and} \quad z_L = \frac{Z_L}{Z_0}$$

then the complex reflection factor is

$$P_L = \frac{z_L - 1}{z_L + 1}$$

and

$$\text{VSWR} = \frac{1 + |P_L|}{1 - |P_L|}, \quad \text{PCR} = |P_L|^2$$

Input Terms

The input impedance, $Z_i = \text{Re}(Z_i) + j\text{IM}(Z_i)$, at a distance DW from termination is computed by the following sequence.

$$|P_i| = |P_L| (10^{-0.1AC})^{DW}, \quad \angle P_i = \angle P_L - 4\pi(DW)$$

$$z_i = \frac{1 + P_i}{1 - P_i}, \quad Z_i = Z_0 z_i$$

Note that this sequence applies in the reverse direction (from Z_i to Z_L) if DW is entered as a negative quantity.

Then the admittance, voltage standing wave ratio, and power reflection coefficient are

$$Y_i = \frac{1}{Z_i} \quad , \quad \text{VSWR} = \frac{1 + |P_i|}{1 - |P_i|} \quad , \quad \text{PCR} = |P_i|^2$$

STEP 1: Be sure that the disk drive or cassette/recorder is attached to the computer and turned on. (See the owner's manuals or the Users Reference Guide for product details.)

STEP 2: Press any key to pass the title screen. Then press 1 to select TI BASIC. To load the program from diskette, insert the diskette into Disk Drive 1, type

OLD DSK1.SMITHCRT

and press ENTER.

To load the program from a cassette tape, insert the tape into the recorder. Next, refer to the "Loading Cassettes" section in this manual for instructions on determining the program's position on the cassette tape. When you have inserted the cassette tape and properly positioned the tape counter, type

OLD CS1

and press ENTER. The computer then displays directions for loading the program. Refer to "Loading Cassettes" if you have difficulty in loading the program from the cassette.

STEP 3: When the cursor reappears, type RUN, and press ENTER. The SMITH CHART CALCULATIONS title screen appears. Press ENTER to continue.

STEP 4: Now enter the value of Z0 in ohms (enter as A+JB if complex, where A and B are numeric values). Next, choose between entering the termination impedance or admittance. To enter impedance, type "ZL=" followed by its value in ohms. To enter admittance, type "YL=" followed by its value in mhos. To complete the required information, enter the value of the attenuation constant in decibels/wavelength and the distance from termination in wavelengths.

STEP 5: The computer automatically displays the values you entered, along with the results of the calculations. The input values--Z_I, Y_I, VSWR, and PCR--and the termination values--VSWR and PCR--are displayed. You then have the option of changing your entries, repeating the program, or exiting the program. To change your input, simply press C. Type the variable and its new value (i.e., DW=2) and press ENTER. To change more than one input, type both changes and separate them with a semicolon. When you press ENTER, the program recalculates the results and displays them along with the values you entered. To repeat the program, press R, and the program asks you for new data entries. When you finish your calculations, press E to exit the program. The message ****DONE**** is displayed, and the program stops.

SMITH CHART CALCULATIONS

Example

To help you understand how the program works, the following example is provided.

Given a transmission line with a characteristic impedance (Z_0) of $50 + j0$ ohms, an attenuation constant of 0.4 dB, and a termination impedance of $10 + j40$ ohms, find the input impedance (Z_i) and the input VSWR at 1 and 2 wavelengths (DW) from the termination.

First, load and run the program as described in Steps 1 and 2 of the "User Instructions." Now enter the required inputs in response to the prompts shown below.

PROMPT	ENTER	COMMENTS
CHARACTERISTIC IMPEDANCE? Z0=	50	Z_0 in ohms
TERM LOAD (ZL= or YL=)?	ZL=10+J40	Z_L in ohms
ATTENUATION CONSTANT IN DB/WAVELENGTH? AC =	.4	AC in dB/wavelength
DISTANCE FROM TERMINATION IN WAVELENGTH? DW =	1	DW in wavelengths

The values you entered and the computed results are displayed as follows.

INPUT SUMMARY:

Z0 = 50
ZL = 10 + J40
AC = .4
DW = 1

INPUT VALUES:

ZI = 13.6 + J39.1
YI = .007 + J.022
VSWR = 6.02839
PCR = .511854

TERMINATION VALUES:

VSWR = 8.27921
PCR = .615384

PRESS (C)HANGE, (R)EDO, (E)XIT

SMITH CHART CALCULATIONS

Example

Now press C to change the distance from termination to 2 wavelengths. Type DW = 2, and press ENTER. Your entry values and answers are displayed as follows.

INPUT SUMMARY:

Z0 = 50
ZL = 10 + J40
AC = .4
DW = 2

INPUT VALUES:

ZI = 17 + J38
YI = .009 + J.021
VSWR = 4.75521
PCR = .425742

TERMINATION VALUES:

VSWR = 8.27921
PCR = .615384

PRESS (C)HANGE, (R)EDO, (E)XIT

Press E. The message ****DONE**** is displayed, and the program stops.

Copies of all programs listed on the cassette tape label are located on both sides of the tape. If for any reason you experience trouble loading or accidentally erase a program, another copy is available on the other side of the tape.

To attach and operate your cassette recorder, refer to the User's Reference Guide. Follow these instructions carefully, and the programs should load easily.

However, if your recorder does not respond when you press ENTER while loading the package, the cassette recorder's drive motor may not be compatible with the Home Computer's circuitry. Although the computer may not be able to operate the cassette automatically, you may be able to operate your cassette manually. Connect the red and white plugs to the cassette unit as described in the User's Reference Guide, but do not connect the black plug. Follow the procedure for loading data as described. When the message "PRESS CASSETTE PLAY" is displayed, press the ENTER key immediately after pressing the cassette's PLAY keys. If the data is loaded successfully, you may continue to operate the cassette manually.

To locate the position of programs on a cassette, listen to the tape and note the counter setting when programs begin. Follow these steps to determine the exact location of all programs:

- STEP 1: Rewind your tape and reset the counter to zero.
- STEP 2: Disconnect the computer-to-cassette cable from the cassette player. You now can hear what is on the tape as it plays.
- STEP 3: Press PLAY.
- STEP 4: The programs on Electrical Engineering Library are listed on the cassette tape in the following order:

- FILTER DESIGN
- PHASE-LOCKED LOOP DESIGN
- ROOT LOCUS CALCULATIONS
- SMITH CHART CALCULATIONS

A blank section of tape precedes each program. When you hear program data, note the position of the counter beside the program name above. You may wish to subtract 1 or 2 from the counter reading to ensure that, when you load the program, the beginning of your program loads properly.

STEP 5: Use these counter settings in the future to quickly load cassette tape programs.

NOTE: This process can be speeded by alternating between PLAY and FAST FORWARD as you listen.

1. Be sure that the diskette or cassette you are using is the correct one. For a diskette, use the Catalog command on your Disk Manager Command Module to check for the correct program; for a cassette tape, check the label.
2. If your computer does not respond to the RUN command, be sure to select TI BASIC and load the program before you try to use it.
3. Ensure that your cassette recorder or disk system is properly connected and turned on. Be certain that you have turned on all peripheral devices before you turn on the computer.
4. If your program does not appear to be working correctly, press SHIFT C (CLEAR) and remove the diskette from the disk drive or the cassette from the recorder. Reinsert the diskette or the cassette, and follow the "User Instructions" carefully. If the program still does not appear to be working properly, remove the cassette from the recorder or the diskette from the disk drive, turn the computer off, wait several seconds, and turn it on again. Then load the program again.
5. If you are having difficulty in operating your Home Computer or are receiving error messages, refer to the "Maintenance and Service Information" and "Error Messages" appendices in your User's Reference Guide for additional help.
6. If you continue to have difficulty with your Texas Instruments computer or the Electrical Engineering Library package, please contact the dealer from whom you purchased the unit or package for service directions.

**THREE-MONTH LIMITED WARRANTY
HOME COMPUTER SOFTWARE MEDIA**

Texas Instruments Incorporated extends this consumer warranty only to the original consumer purchaser.

WARRANTY COVERAGE

This warranty covers the case components of the software package. The components include all cassette tapes, diskettes, plastics, containers, and all other hardware contained in this software package ("the Hardware"). This limited warranty does not extend to the programs contained in the software media and in the accompanying book materials ("the Programs").

The Hardware is warranted against malfunction due to defective materials or construction. THIS WARRANTY IS VOID IF THE HARDWARE HAS BEEN DAMAGED BY ACCIDENT OR UNREASONABLE USE, NEGLIGENCE, IMPROPER SERVICE OR OTHER CAUSES NOT ARISING OUT OF DEFECTS IN MATERIAL OR CONSTRUCTION.

WARRANTY DURATION

The Hardware is warranted for a period of three months from the date of original purchase by the consumer.

WARRANTY DISCLAIMERS

ANY IMPLIED WARRANTIES ARISING OUT OF THIS SALE, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE ABOVE THREE MONTH PERIOD. TEXAS INSTRUMENTS SHALL NOT BE LIABLE FOR LOSS OF USE OF THE HARDWARE OR OTHER INCIDENTAL OR CONSEQUENTIAL COSTS, EXPENSES, OR DAMAGES INCURRED BY THE CONSUMER OR ANY OTHER USER.

Some states do not allow the exclusion or limitation of implied warranties or consequential damages, so the above limitations or exclusions may not apply to you in those states.

LEGAL REMEDIES

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

PERFORMANCE BY TI UNDER WARRANTY

During the three month warranty period, defective Hardware will be replaced when it is returned postage prepaid to a Texas Instruments Service Facility listed below. The replacement Hardware will be warranted for a period of three months from date of replacement. TI strongly recommends that you insure the Hardware for value prior to mailing.

TEXAS INSTRUMENTS CONSUMER SERVICE FACILITIES

U. S. Residents:

Texas Instruments Service Facility
P. O. Box 2500
Lubbock, Texas 79408

Canadian Residents:

Geophysical Services Incorporated
41 Shelley Road
Richmond Hill, Ontario, Canada L4C5G4

Consumers in California and Oregon may contact the following Texas Instruments offices for additional assistance or information.

Texas Instruments Exchange Center
831 South Douglas Street
El Segundo, California 90245
(213) 973-1803

Texas Instruments Consumer Service
6700 Southwest 105th
Kristin Square, Suite 110
Beaverton, Oregon 97005
(503) 643-6758

IMPORTANT NOTICE OF DISCLAIMER REGARDING THE PROGRAMS

The following should be read and understood before purchasing and/or using the software media.

TI does not warrant the Programs will be free from error or will meet the specific requirements of the consumer. The consumer assumes complete responsibility for any decisions made or actions taken based on information obtained using the Programs. Any statements made concerning the utility of the Programs are not to be construed as express or implied warranties.

TEXAS INSTRUMENTS MAKES NO WARRANTY, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, REGARDING THE PROGRAMS AND MAKES ALL PROGRAMS AVAILABLE SOLELY ON AN "AS IS" BASIS.

IN NO EVENT SHALL TEXAS INSTRUMENTS BE LIABLE TO ANYONE FOR SPECIAL, COLLATERAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING OUT OF THE PURCHASE OR USE OF THE PROGRAMS AND THE SOLE AND EXCLUSIVE LIABILITY OF TEXAS INSTRUMENTS, REGARDLESS OF THE FORM OF ACTION, SHALL NOT EXCEED THE PURCHASE PRICE OF THE SOFTWARE MEDIA. MOREOVER, TEXAS INSTRUMENTS SHALL NOT BE LIABLE FOR ANY CLAIM OF ANY KIND WHATSOEVER BY ANY OTHER PARTY AGAINST THE USER OF THE PROGRAMS.

Some states do not allow the exclusion or limitation of implied warranties or consequential damages, so the above limitations or exclusions may not apply to you in those states.



TEXAS INSTRUMENTS
INCORPORATED
DALLAS, TEXAS